

Always check our website for the most updated specifications: www.zumacollection.com







Pictured with optional waste and overflow

All bathtub dimensions are ± 1/2".

#### **CODES AND COMPLIANCE**

Products meet or exceed the following standards:

- Underwriters Laboratories (UL)
- Underwriters Laboratories Canada (cUL)
- ANSI Z124.1 ANSI A112-19.7
- ANSI A112.19.8

### **ELECTRICAL REQUIREMENTS**

We recommend one 20 amp ground fault circuit interrupter (GFCI) for each power supply provided with the bathtub.

#### **DIMENSIONS**

66" x 44" x 22"

Whirlpool Operating Gallons: 55


Gallons to Overflow: 85


## Material: Acrylic

# Whirlpool


# Combination


(pump and blower location only)





# **Airbath System II**





# OPTIONAL

# ACCESSORIES

Chromotherapy Light Grab Bars

High Density Insulation iBath Sound System Lo-Profile Tub Edge Ozone System

(Whirlpool and/or Airbath only)

Pillow -12"

**Rotary Jets** 

Thermal Comfort System

(TCS must be at opposite end if used with VSM)

Trim Kit Upgrade Vibro Sonic Massage

(VSM must be at opposite end if used with TCS)

Waste & Overflow Linear Overflow

Undermount

Yes X

No

## INSTALLATION TIPS

- Install product according to Owners manual and local codes.
- All whirlpool or Airbath<sup>®</sup> units require an access panel.
- Hot water supply should be 65-75% of tub capacity or greater. Always consult your local plumber for recommendations as installations will vary.
- Dimensions for undermount installations should be taken directly from the bathtub.
- Cut-out dimensions: Zuma recommends you wait until you have the actual unit or contact us for a template.